

## **INSTALLATION OF A DRYWELL**

- 1. The installation site must be at least 10 feet away from structure.**
- 2. Prior to any digging, utility mark outs should be completed.**
- 3. Check Town requirements for inspection.**
- 4. Dig hole until sand is reached.**
- 5. Place drywell into the hole.**
- 6. Place drainage gravel around the outside of the drywell to help percolation into the soil.**
- 7. Place cover on top and run piping from structure to drywell.**